



Disinfectant Wipes

- Kills Antibiotic Resistant Bacteria: MRSA and CA-MRSA
- *Virucidal / Bactericidal / Pseudomonocidal

Active Ingredients

| | |
|---|---------------|
| Alkyl (60% C ₁₄ , 30% C ₁₆ , 5% C ₁₂ , 5% C ₁₈) dimethyl benzyl ammonium chlorides | 0.14% |
| Alkyl (68% C ₁₂ , 32% C ₁₄) dimethyl ethylbenzyl ammonium chlorides | 0.14% |
| Inert Ingredients | 99.72% |
| Total | 100.00% |

KEEP OUT OF REACH OF CHILDREN CAUTION

See side panel for additional precautionary statements.

EPA REG. NO.: 1839-190-71670
EPA EST. NO.: 71670-SC-001
Net Contents: 13 lbs.

900 Pre-moistened Wipes, 9" x 6" (22.9 cm x 15.2 cm)

Part Numbers
Preloaded bucket: ATHD0101 (1 roll/bucket)
Refills: ATHD0201 (2 rolls/case)

VARNISH FREE

2330-12/11

Athletix Disinfectant Wipes will clean and disinfect hard, non-porous surfaces of gym equipment, exercise machines, wrestling mats, gymnastic equipment, grocery cart handles, grocery carts, shopping carts, grocery cart child seats. **Athletix Disinfectant Wipes** will not harm most surfaces including acrylic, fiberglass and vinyl. **Athletix Disinfectant Wipes** are non-woven, disposable wipes, presaturated with a quaternary disinfectant cleaner.

DIRECTIONS FOR USE

It is a violation of Federal Law to use this product in a manner inconsistent with its labeling. This product is not for use on critical and semi-critical medical device surfaces.

CLEANING: Use one **Athletix Disinfectant Wipes** to completely remove all major dirt and debris from surfaces to be treated.

DISINFECTING: To disinfect hard, non-porous surfaces, thoroughly wet the surface to be treated. Treated surface must remain visibly wet for disinfecting. Use enough wipes for treated surface to remain visibly wet for 5 minutes. For heavily soiled surfaces, clean before following disinfecting instructions. Allow surfaces to air dry.

Athletix Disinfectant Wipes are an effective disinfectant against *Escherichia coli* O157:H7 (ATCC 43895), *Pseudomonas aeruginosa* (ATCC 15442), *Salmonella enterica* (Salmonella) (ATCC 10708), *Staphylococcus aureus* (ATCC 6538), *Streptococcus pyogenes* (Strep) (ATCC 19615), Vancomycin resistant *Enterococcus faecium* (VRE) (ATCC 51559), Methicillin resistant *Staphylococcus aureus* (MRSA) (ATCC 33591), Community Associated Methicillin resistant *Staphylococcus aureus* (CA-MRSA) Genotype USA400, Community Associated Methicillin resistant *Staphylococcus aureus* (CA-MRSA) Genotype USA300 and Vancomycin intermediate resistant *Staphylococcus aureus* (VISA) (ATCC 700699).

***VIRUCIDAL ACTIVITY:** **Athletix Disinfectant Wipes** are an effective virucide on hard, non-porous surfaces against Influenza A₂/Japan, Herpes Simplex Virus 1 (ATCC VR-260), Human Immunodeficiency Virus, Type 1 (HIV-1) and Herpes Simplex Virus 2 (ATCC VR-734) when the treated surface is allowed to remain wet for 5 minutes. Allow surfaces to air dry.

KILLS HIV-1 ON PRE-CLEANED ENVIRONMENTAL SURFACES/OBJECTS PREVIOUSLY SOILED WITH BLOOD/BODY FLUIDS in health care settings (Hospitals, Nursing Homes) or other settings in which there is an expected likelihood of soiling of inanimate surfaces/objects with blood or body fluids, and in which the surfaces/objects likely to be soiled with blood or body fluids can be associated with the potential for transmission of Human Immunodeficiency Virus Type 1.

SPECIAL INSTRUCTIONS FOR CLEANING AND DECONTAMINATION AGAINST HIV-1 ON SURFACES/OBJECTS SOILED WITH BLOOD/BODY FLUIDS.

PERSONAL PROTECTION: When handling items soiled with blood or body fluids, use disposable latex gloves, gowns, masks and eye coverings.

CLEANING PROCEDURES: Blood and other body fluids must be thoroughly cleaned from surfaces and objects before application of **Athletix Disinfectant Wipes**.

CONTACT TIME: Allow surfaces to remain wet for 5 minutes.

DISPOSAL OF INFECTIOUS MATERIALS: Blood and other body fluids should be autoclaved and disposed of according to local regulations for infectious waste disposal.

FUNGICIDAL ACTIVITY: **Athletix Disinfectant Wipes** are an effective fungicide against

Trichophyton mentagrophytes (ATCC 9533) (causative agent of Athlete's Foot Fungus), when used as directed on hard surfaces found in bathrooms, shower stalls, locker rooms, exercise facilities or other clean, hard, non-porous, surfaces commonly contacted by bare feet. The surface must remain visibly wet for 3 minutes. Allow surfaces to air dry.

EFFICACY TESTS HAVE DEMONSTRATED THAT ATHLETIX DISINFECTANT WIPES ARE AN EFFECTIVE BACTERICIDE, VIRUCIDE AND FUNGICIDE IN THE PRESENCE OF ORGANIC SOIL (5% BLOOD SERUM).

For surfaces that may come in contact with food, a potable water rinse is required. For plastic and painted surfaces, spot test on an inconspicuous area before use.

- **Do not use on unpainted wood.**
- This is **not** a baby wipe!
- Not for personal cleansing.
- Do not flush in toilet.

TO OPEN PACKAGE: Open lid of the dispenser. Tear open top of bag. Pull out the first wipe approximately 6 to 8 inches from the center of the roll. Place entire bag inside of center pull dispenser. Thread the wipe through the opening on the dispenser. Close the lid of the dispenser.

PRECAUTIONARY STATEMENTS

Hazards to Humans and Domestic Animals

CAUTION: Causes moderate eye irritation. Avoid contact with eyes or clothing. Wash thoroughly with soap and water after handling.

FIRST AID

Have the product container or label with you when calling a poison control center or doctor, or going for treatment.

IF IN EYES: Hold eyes open and rinse slowly and gently with water for 15–20 minutes. Remove contact lenses if present, after the first 5 minutes, then continue rinsing. Call a poison control center or doctor for treatment advice. You may contact 1-800-222-1222 for emergency medical treatment information.

STORAGE AND DISPOSAL

Do not contaminate water, food or feed by storage or disposal.

CONTAINER STORAGE/DISPOSAL: Store in an area inaccessible to children. **Wipes:** Dispose of wipe in trash after use. Do not flush. **Dispenser:** Refill only with this product. Do not reuse or refill except as described in the directions for use. Keep dispenser closed to retain moisture. **Plastic Bag:** Do not reuse or refill empty plastic bag. Offer empty plastic bag for recycling if available or discard in trash.

Made in USA



SOLD BY Contec, Inc.
525 Locust Grove
Spartanburg, SC 29303

Phone: +1-864-503-8333
Email: athletixproducts@contecinc.com
www.athletixproducts.com